


UVC84-BYOD Deployment & Connection


Package Contents

💡 TIP


We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in poor performance.



UVC84 package



VCM34 package



MSpeaker II




Wall Mount Bracket




x 2




x 2

Expansion screws
and Self-tapping screws

Power Adapter




3.5mm Audio Cable




Silicone Pad x2

MSpeaker II
Quick Start Guide

MSpeaker II package




MSpeech



Silicone Pad

MSpeech
Quick Start Guide

MSpeech package



BYOD-BOX

PD
Power Adapter

1.2m USB Type-C Cable



Velcrox2

Type-C to Type-A
AdapterBYOD
Quick Start Guide

BYOD-BOX package

Installation

For installation guides, refer to the following links:

- [UVC84](#)
- [VCM34](#)


- MSpeaker II

Connect UVC84-BYOD


You can choose one of the following connection options:

- **Connection A:** Applicable to large meeting rooms (UVC84-VCM34x2-MSpeaker II).
- **Connection B:** Applicable to medium-sized meeting rooms (UVC84-MSpeech-BYOD).

Connection A



Connection B



Deploy UVC84-BYOD

Attach the BYOD box to the bottom or the top of the table.

